

GREEN ARMOR TO HARD ARMOR TRANSITION

SEE PAGE 2 FOR DETAIL
USE TWO BLOCK MINIMUM BURIED

FUTERRA® 7003/7010/7020/R45 TRM

ACB
REVTMENT

ELEVATION 2.5 FT

VARIES
1

ELEVATION 0.0 FT

SITE SPECIFIC
GEOTEXTILE

NATIVE SOIL

PLEASE NOTE THAT THE INFORMATION PRESENTED HEREIN IS GENERAL INFORMATION ONLY. IT IS FOR CONCEPTUAL USE ONLY AND NOT INTENDED TO BE USED FOR CONSTRUCTION. WHILE EVERY EFFORT HAS BEEN MADE TO ENSURE ITS ACCURACY, THIS INFORMATION SHOULD NOT BE USED FOR A SPECIFIC APPLICATION WITHOUT INDEPENDENT PROFESSIONAL EXAMINATION AND VERIFICATION OF ITS SUITABILITY, APPLICABILITY AND ACCURACY.



**GREEN DESIGN
ENGINEERING™**
EARTH-FRIENDLY SOLUTIONS
FOR SUSTAINABLE RESULTS™

GREENARMOR™ – HARD
ARMOR TRANSITION DETAILS

FILE NAME: Green Armor to Hard Armor
Transition Details Sheet 1 or 2.dwg

CONTACT: 800-508-8681 (US & Canada)
+1-847-215-1144 (International)

WEB SITE: www.profileproducts.com



Solutions for your Environment™

DRAWN BY: MDR

DATE: 06/27/08

SCALE: NOT TO SCALE

CHECKED BY: RPH

DATE: 04/07/17

SHEET 1 OF 2